

Tankguard DW

Product description

This is a two component solvent free amine cured epoxy coating. It is specially designed for drinking water tanks. Can be used as primer and finish coat in atmospheric and immersed environments. Suitable for properly prepared carbon steel, stainless steel and concrete substrates.

Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist in smooth and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements. Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

Referred standards

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

Surface preparation

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

When preparing new surfaces, maintaining already coated surfaces or aged coatings it is necessary to remove all contamination that can interfere with coating adhesion, and prepare a sound substrate for the subsequent product. Inspect the surface for hydrocarbon and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area using fresh water. Paint solvents (thinners) shall not be used for general degreasing or preparation of the surface for painting due to the risk of spreading dissolved hydrocarbon contamination. Paint thinners can be used to treat small localized areas of contamination such as marks from marker pens. Use clean, white cotton cloths that are turned and replaced often. Do not bundle used solvent saturated cloths. Place used cloths into water. When the surface is an existing coating, verify with technical data sheet and application guide of the involved products, both over coatability and the given maximum over coating interval.

Process sequence

Surface preparation and coating should normally be commenced only after all welding, degreasing, removal of sharp edges, weld spatter and treatment of welds is complete. It is important that all hot work is completed before coating commences.

Soluble salts removal

Soluble salts have a negative impact on the coating systems performance, especially when immersed. Jotun's general recommendations for maximum soluble salts (sampled and measured as per ISO 8502-6 and -9) content on a surface are: Potable water tanks: 50 mg/m²

Carbon steel

Initial rust grade

Date of issue: 14 October 2015

Page: 1/10

This Application Guide supersedes those previously issued.



The steel shall preferably be Rust Grade A or B (ISO 8501-1). It is technically possible to apply the coating to rust grades C and D, but it is practically challenging to ensure specified film thickness on such a rough surface, hence risk of reduced lifetime of the coating system. When steel of Rust Grade C or D is coated, the frequency of inspection and testing should be increased.

Metal finishing

For areas in corrosivity category C1 to C4 (ISO 12944-2) all irregularities, burrs, slivers, slag and spatter on welds, sharp edges and corners shall conform to minimum grade P2 (ISO 8501-3) Table 1, or as specified. All edges shall have a rounded radius of minimum 2 mm subjected to three pass grinding or equally effective method. For areas in corrosivity category C5, Im1-3 the requirement is for the steel to conform to grade P2 (ISO 8501-3) Table 1. All edges shall have a rounded radius of minimum 2 mm subjected to three pass grinding or equally effective method. One may use a mechanical grinder fitted with a suitable abrasive disc. All sharp irregularities, burrs, slivers, slag and spatter on welds, whether apparent before or after blast cleaning, shall be removed before coating application. It is recommended that welding smoke should be removed by low-pressure Water Cleaning LP WC method (ISO 8501-4:2006) Wa 1 using fresh water. Welding smoke residues are water soluble and could cause blistering if not removed by washing before blasting. Defective welds shall be replaced and treated to an acceptable finish before painting. Temporary welds and brackets shall be ground to a flat finish after removal from the parent metal. Surface preparation and coating should normally be commenced only after all metal finishing and degreasing of a specific area is complete. It is important as much hot work as possible is completed before coating commences.

Pitting repair

Pittings in steel can be difficult to cover fully with most coatings. In some areas it is practically feasible to use filler to fill pittings. This should then be done either after the initial surface preparation or after application of first coat. For tank coating and lining used for chemical exposure the recommendation is to fill pitts through welding, since using fillers may negatively affect the coating systems' chemical resistance and flexibility.

Abrasive blast cleaning

Application of protective coating shall commence before degradation of the surface standard occurs.

Cleanliness

After pre-treatment is complete, the surface shall be dry abrasive blast cleaned to Sa $2\frac{1}{2}$ (ISO 8501-1) using abrasive media suitable to achieve a sharp and angular surface profile.

Surface profile

Recommended surface profile 50-100 μ m, grade Fine to Medium to G; Ry5 (ISO 8503-2). Measure the achieved profile with surface replication tape (Testex) to ISO 8503-5 or by a surface roughness stylus instrument (ISO 8503-4).

Abrasive media quality

The selected abrasive must be compatible with both the surface to be blast cleaned and the specified coating system. The abrasive shall meet specifications as per relevant parts of ISO 11124 (Specification for metallic blast-cleaning abrasives), or ISO 11126 (Specification for non-metallic blast-cleaning abrasives). It should be sampled and tested as per relevant parts of ISO 11125 (metallic abrasives) or ISO 11127 (non-metallic abrasives). Dry storage of abrasive and shelter for blasting pots is necessary to prevent equipment becoming clogged with damp abrasive.

All abrasive blast media used should be new and not recirculated, with the exception of Steel Grit. If this is utilized the circulation process must include a cleaning process.

Compressed air quality

The supply of clean air to blasting pots must be secured to avoid contamination of abrasive and thereby of blast cleaned surfaces. Compressors must be fitted with sufficient traps for oil and water. It is also recommended to fit two water separators at the blasting machine to ensure a supply of moisture-free air to the abrasive chamber.

Dust contamination

At the completion of abrasive blasting the prepared surface shall be cleaned to remove residues of corrosion product and abrasive media and inspected for surface particulate contamination. Maximum contamination level is rating 1 (ISO 8502-3) as per Figure 1. Dust size no greater than class 2.

Date of issue: 14 October 2015

This Application Guide supersedes those previously issued.



Hand and Power Tool Cleaning

Power tool cleaning

Minor damage of the coating may be prepared to St 3 (ISO 8501-1). Suitable method is disc grinding with rough discs only. Ensure the surface is free from mill scale, residual corrosion, failed coating and is suitable for painting. The surface should appear rough and mat. Overlapping zones to intact coating shall have all leading edges feathered back by sanding methods to remove all sharp leading edges and establish a smooth transition from the exposed substrate to the surrounding coating. Consecutive layers of coating shall be feathered to expose each layer and new coating shall always overlap to an abraded existing layer. Abrade intact coatings around the damaged areas for a minimum 100 mm to ensure a mat, rough surface profile, suitable for over coating.

Stainless steel

Abrasive blast cleaning

The surface to be coated shall be dry abrasive blast cleaned as required for the specified surface profile using non-metallic abrasive media which is suitable to achieve a sharp and angular surface profile. As a guide, a surface profile corresponding to 25-55 μ m, grade Fine G; Ry5 (ISO 8503-2) should be achieved. Examples of recommended abrasives are:

- Ferrite free almandite garnet grade 30/60 and 80 grade (US Mesh size)
- Aluminium oxide grade G24

Chlorinated or chlorine containing solvents or detergents must not be used on stainless steel.

Concrete

Concrete should be a minimum of 28 days old, applying any coating before this time will greatly increase the chance of the coating de-bonding. The moisture content of the concrete should be checked prior to the application of the coating and should not be greater than 5%. Concrete substrates should be mechanically prepared to leave a clean, sound and dry base on which a coating system can be applied.

Clean – Free of oils, grease, dust, dirt, chemicals, loose coating, curing compounds, form release oils, sealers or hardeners must be removed prior to coating.

Sound – Concrete that has unsound areas (voids, hollow spots, and friable surface) may have to be removed, replaced or repaired with materials that are compatible with the selected coating system.

Dry – It is important to address dryness because most coatings require a dry surface for proper adhesion. Moisture contained within the concrete that moves towards the surface through the pores of the concrete may prevent adequate coating adhesion.

Dry abrasive blast cleaning to SSPC-SP 13/NACE No. 6. Where the concrete has become contaminated with oils, grease, or fuels, water emulsifiable degreasers-cleaners may be used to remove these contaminants. It is important to only clean an area that can be fully washed down after degreasing before any of the cleaner can dry on the surface.

Ultra high pressure water jetting can be used to remove laitance and reveal blowholes and imperfections. Ensure concrete is dry before coating application.

Sand sweeping

Dry abrasive blast cleaning to SSPC-SP 13/NACE No. 6. All prepared surfaces should then have all "blow holes" and other surface defects filled with suitable filler that is compatible with the primer and finish coat system to ensure that the coating can be applied over a smooth and regular substrate.

Diamond disc grinding

Diamond grind the surface to remove all laitance and expose the aggregates.

Coated surfaces

Shop primers

Shop primers are accepted as temporary protection of steel plates and profiles. However the shopprimer should be completely removed through blast cleaning to minimum Sa $2\frac{1}{2}$ (ISO 8501-1) using abrasive media suitable to achieve a sharp and angular surface profile 50-100 μ m, grade Medium G; Ry5 (ISO 8503- 2).

Date of issue: 14 October 2015

This Application Guide supersedes those previously issued.



Application

Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

Standard grade

Air temperature	10 - 50	°C
Substrate temperature	10 - 60	°C
Relative Humidity (RH)	10 - 60	%

The following restrictions must be observed:

• Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point

• Do not apply the coating if the substrate is wet or likely to become wet

• Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing

• Do not apply the coating in high wind conditions

Product mixing

Product mixing ratio (by volume)

Tankguard DW Comp A	2 part(s)
Tankguard DW Comp B	1 part(s)

Induction time and Pot life

Paint temperature	23 °C	
Induction time Pot life	10 min	
Pot life	1 h	

Reduced at higher temperatures

The temperature of base and curing agent is recommended to be 18 °C or higher when the paint is mixed.

Thinner/Cleaning solvent

Do not add thinner.

Cleaning equipment Prior to application: Jotun Thinner No. 28 After application: Jotun Thinner No. 17

Date of issue: 14 October 2015

This Application Guide supersedes those previously issued.



Application data

Airless Spray Equipment

Pump ratio (minimum) :	64:1
Pump output (litres/minute) :	1.5-2.6
Pressure at nozzle (minimum) :	175 bar/2500 psi
Nozzle tip (inch/1000) :	19-25
Filters (mesh) :	50-70

Material hose length :

Several factors influence, and need to be observed to maintain the recommended pressure at nozzle. Among factors causing pressure drop are:

- long paint- and whip hoses

- low inner diameter hoses

- high paint viscosity

large spray nozzle size

- inadequate air capacity from compressor

- wrong or clogged filters

Plural component (Twin Pump) airless spray equipment

Using two-component pump is highly recommended in order to achieve an optimum spray pattern, especially during application at lower temperatures. When applying at higher temperatures use of two-component pump eliminates the challenge with reduced pot life.

When using plural spray equipment, Jotun recommends the use of either a pump with computerised pump ratio settings or fixed ratio settings in combination with a flow meter for each pump to monitor the proper delivery ratio of the coating components is maintained during use.

Recommended data for pump output, pressure at nozzle, nozzle tip and filters are the same as for airless spray equipment.

Other application tools

Roller application

Roller application only to be used for scallops, ratholes, small pipes etc.

Film thickness per coat

Typical recommended specification range

Dry film thickness	150	-	400	μm
Wet film thickness	150	-	400	μm
Theoretical spreading rate	6,7	-	2,5	m²/l

Can be applied up to 25 % higher than maximum specified film thickness without loss of technical properties.

Date of issue: 14 October 2015

This Application Guide supersedes those previously issued.



Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A). Use a wet-to-dry film calculation table to calculate the required wet film thickness per coat. A wet to dry film thickness chart is available on the Jotun Web site.

Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 cm from the weld.

Application / Drying / Curing considerations

Pay close attention to both spraying technique and the correct setting of equipment during application in order to achieve an even, pinhole free film. A combination of the correct inbound air / outbound material pressure, correct airless tip or spray set up and a 30-50 cm gun to substrate distance is recommended. Apply the coating in even and uniform parallel passes and overlap each pass 50% to achieve an even film. Use a painter's wet film comb during application to control the wet to dry film thickness of the coating.

Ventilation

As a guideline for good ventilation, after application of each coat the confined space should be ventilated with 3-5 cycles per hour. After final coat maintain 3-5 cycles per hour for minimum 48 hours. Thereafter the number of cycles can be reduced to 1-2 cycles per hour until coating is fully cured.

Stripe coating

The stripe coat sequence can be either of the following:

1. Surface preparation, full coat, stripe coat. This sequence can be used when a large substrate area has been prepared and leaving the substrate exposed for a long time while doing stripe coating could lead to surface deterioration.

2. Surface preparation, stripe coat, full coat.

In general Jotun recommends alternative 1 because it reduces the risk that "new" contamination will be introduced to the uncoated substrate.

Walking on the blast cleaned substrate in order to do the stripe coating presents a risk for such contamination. It is important to pay special attention to edges, openings, rear sides of stiffeners, scallops etc. and to apply a stripe coat to these areas where the spray fan may not reach or deposit an even film.

When applying a stripe coat to bare metal use only a stiff, round stripe coating brush to ensure surface wetting and filling of pits in the surface. Stripe coating shall be of a different colour to the main primer coat and the topcoat colour and should be applied in an even film thickness, avoiding excessive brush marks in order to avoid entrapped air. Care should be taken to avoid excessive film thickness. Pay additional attention to pot life during application of stripe coats. Jotun recommends a minimum of one stripe coat. A second stripe coat will be beneficial in order to ensure that sufficient paint material is applied to the critical parts of the object.

Coating loss

The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss. Some of the factors that can influence the loss of coating material are:

- type of spray gun/unit used
- air pressure used for airless pump or for atomization
- orifice size of the spray tip or nozzle
- fan width of the spray tip or nozzle
- the amount of thinner added
- the distance between spray gun and substrate
- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target
- environmental conditions such as wind and air temperature

Date of issue: 14 October 2015

Page: 6/10

This Application Guide supersedes those previously issued.



Drying and Curing time

Substrate temperature	10 °C	23 °C	40 °C
Surface (touch) dry	15 h	10 h	3 h
Walk-on-dry	25 h	13 h	5 h
Dry to over coat, minimum	25 h	13 h	5 h
Dry to over coat, maximum, atmospheric	10 d	5 d	3 d
Dried/cured for service	14 d	7 d	4 d
Dried/cured for immersion	10 d	5 d	3 d

Drying and curing times are determined under controlled temperatures and relative humidity below 60 %, and at average of the DFT range for the product.

Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Walk-on-dry: Minimum time before the coating can tolerate normal foot traffic without permanent marks, imprints or other physical damage.

Dry to over coat, minimum: The shortest time allowed before the next coat can be applied.

Dry to over coat, maximum, atmospheric: The longest time allowed before the next coat can be applied.

Dried/cured for service: Minimum time before the coating can be permanently exposed to the intended environment/medium.

Dried/cured for immersion: Minimum time before the coating can be permanently immersed in sea water.

Maximum over coating intervals

Maximum time before thorough surface preparation is required. The surface must be clean and dry and suitable for over coating. Inspect the surface for chalking and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water jetting to Wa 1 (ISO 8501-4) using fresh water.

If maximum over coating interval is exceeded the surface should in addition be carefully roughened to ensure good inter coat adhesion.

Areas for atmospheric exposure

10 °C	23 °C	40 °C	
10 d	5 d	3 d	
10 °C	23 °C	40 °C	
10 d	5 d	3 d	
	10 d 10 °C	10 °C 23 °C	10 d 5 d 3 d 10 °C 23 °C 40 °C

Other conditions that can affect drying / curing / over coating

Repair of coating system

Date of issue: 14 October 2015

Page: 7/10

This Application Guide supersedes those previously issued.



Damages to the coating layers:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is clean and dry the coating may be over coated by itself or by another product, ref. original specification.

Always observe the maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion. Damages exposing bare substrate:

Remove all rust, loose paint, grease or other contaminants by spot blasting, mechanical grinding, water and/or solvent washing. Feather edges and roughen the overlap zone of surrounding intact coating. Apply the coating system specified for repair.

Repair of damaged areas

Sags and runs can be caused by too high wet film thickness, too much thinner added or the spray gun used too close to the surface.

Repair by using a paint brush to smooth the film when still wet.

Sand down to a rough, even surface and re-coat if the coating is cured. Orange peel can be caused by poor flow/ levelling properties of the paint, poor atomization of the paint, thinner evaporating too fast or the spray gun held too close to the surface.

This can be rectified by abrading the surface and applying an additional coat after having adjusted the application properties or the application technique. Dry spray can be caused by poor atomization of the paint, spray gun held too far from the surface, high air temperature, thinner evaporating too fast or coating applied in windy conditions. Sand down to a rough even surface and re-coat. Pinholes can be caused by entrapped solvents in the film or by incorrect application technique. Pinholes can be repaired as per procedure for damages to the coating layer or to the substrate, ref. above.

Surface finish

Amine sweating may occur when amine cured epoxy coatings are cured at low temperatures and/or humid conditions. Amine sweating can sometimes be observed on the surface as a sticky residue or as discolouration. It can seriously affect the adhesion of the subsequent coat and must be removed. If amine sweating is suspected, wash the surface with warm water and detergent, and rinse thoroughly with water. Light abrasion of the surface and removal of dust before over coating will further secure good intercoat adhesion. Amine sweating can be minimized by observing the induction time stated in TDS.

Coating film continuity

Jotun recommends that all coating systems for immersion shall be inspected for film continuity/defects by visual observation of pin hole rusting through the coating after tank hydro-testing or sea water immersion during sea trials. Alternatively, full immersion of tanks in combination with tanks fully saturated by tank cleaning machine(s), soaking all surfaces with sea water and creating a high condensation environment during sea trials.

All noted defects shall be repaired or reported as outstanding issues.

For onshore storage tanks or for tanks where sea water immersion may not be permitted or practical, coating shall be tested for film continuity/defects as described in ASTM D 5162, method A or B as appropriate for the coating thickness.

The recommended voltage is 500 volts per 100 μ m DFT. The acceptance criterion is no defects. Defects found shall be repaired as per coating specification.

Quality assurance

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation

- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAQ

- Confirm that the required surface preparation standard has been achieved and is held prior to coating application

- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application

- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing

- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle

- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination

Date of issue: 14 October 2015

Page: 8/10

This Application Guide supersedes those previously issued.



Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious pinholes, excessive dry spray, heavy brush marks and excessive film build
Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

Caution

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

Health and safety

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

Accuracy of information

Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

Colour variation

Some coatings used as the final coat may fade and chalk in time when exposed to sunlight and weathering effects. Coatings designed for high temperature service can undergo colour changes without affecting performance. Some slight colour variation can occur from batch to batch. When long term colour and gloss retention is required, please seek advice from your local Jotun office for assistance in selection of the most suitable top coat for the exposure conditions and durability requirements.

Reference to related documents

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

Symbols and abbreviations

min = minutes	TDS = Technical Data Sheet
h = hours	AG = Application Guide
d = days	SDS = Safety Data Sheet
°C = degree Celsius	VOC = Volatile Organic Compound
° = unit of angle	MCI = Jotun Multi Colour Industry (tinted colour)
µm = microns = micrometres	RAQ = Required air quantity
g/l = grams per litre	PPE = Personal Protective Equipment
g/kg = grams per kilogram	EU = European Union
m ² /l = square metres per litre	UK = United Kingdom
mg/m ² = milligrams per square metre	EPA = Environmental Protection Agency
psi = unit of pressure, pounds/inch ²	ISO = International Standards Organisation
Bar = unit of pressure	ASTM = American Society of Testing and Materials
RH = Relative humidity (% RH)	AS/NZS = Australian/New Zealand Standards
UV = Ultraviolet	NACE = National Association of Corrosion Engineers
DFT = dry film thickness	SSPC = The Society for Protective Coatings
WFT = wet film thickness	PSPC = Performance Standard for Protective Coatings
	IMO = International Maritime Organization

Date of issue: 14 October 2015

Page: 9/10

This Application Guide supersedes those previously issued.



Disclaimer

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.

Date of issue: 14 October 2015